

Saviour Standard Harness + Saviour Double PP Lanyard Scaffold Hook

Model No: FPSAV-110



Before wearing check following points:

1. Check webbing of Harness fully if it is cutted/burnt from anywhere.
2. Check all metal parts of Harness like buckles, Dorsal D-ring, chest buckle and if it is rusted anywhere then don't use.
3. Check stitched parts of the harness and all stiches should be ok.
4. Lanyard rope should not in cut/burnt condition anywhere.
5. Lanyard thimble part contains plastic cover and it should be in good
6. condition. Inside thimble ropes knots not to be in opened condition.
7. Hooks of Lanyard need to be open/close in freely, should not be rusted.
8. If there is Fall Indicator below Dorsal D-ring then it should not be in open condition.
9. If above condition are ok then use Safety Harness

Self-life : 5 Years

Warranty :

1 Year against any manufacturing defect.

SURE SAFETY (INDIA) PVT. LTD.

Chhani, Vadodara-391 740 Gujarat INDIA

☎ : +91-265-2760150 / 162, ☎ : +91-265-2774824

✉ : info@suresafety.com 🌐 : www.suresafety.com

REGISTERED UNDER MSME ACT, 2006. / REG. NO DIC/VAD/EM/PART-2/10979 DT. 01.04.2013

CIN : U31903GJ2013PTC073194