



SAVIORUR 'FR' Coverall



General Description:

Protection of all body parts is a must in any manufacturing facility. Work suits which can accommodate basic tools and Tackles for normal working which are carried along and also providing formal protection during the work hours and are comfortable to wear are preferred.

"Saviour" Body Protection Suits are just the right product for such applications as they are made up of soft cotton Fabrics. It is also necessary when working in all segments of the Industry where spillages, abrasion or fire of any kind is anticipated.

MODEL NO: BPSAV-FRS / BPSAV-IFRS

Specifications

“Saviour” Body Protection Coveralls are made up of 100% cotton with FR Properties. Fabric is closely knitted which ensures maximum heat dissipation and provides comfort to the wearer. The suit is doubly stitched with good quality thread and is made as a ‘One-Piece’ garment covering the full body from Neck to ankle. It comes with a collar with one front pocket on the left side of the chest of the upper Torso with two pockets on the Thighs of the suit. The suit is open in the front till crotch and is provided with No 5 metallic Zipper. The waist is elasticized for snug fitting and these are available in all sizes as prevalent in the Industry. All components of FR garments (e.g., Sewing threads, zipper, Reflective tapes) are made from FR material. All metal components are backed with FR material to prevent the components from conducting heat to the wearer’s skin. All elastic bands and Velcro are fully covered and backed with FR material to prevent ignition or melting of these components.

Material: 100% Cotton with FR Properties.

Color: Navy Blue, Royal Blue, Orange.

Company Logo: As per customer requirement, if required.

Applications

- ◆ Work wear for all Industrial segments.
- ◆ Oil & Gas Segments and installations.
- ◆ Onshore & Offshore sites and Rigs.

Advantage

- ◆ Light weight and comfortable to wear.
- ◆ Breathable fabric yet Fire Retardant in Nature.
- ◆ Replacement of heavy garments.
- ◆ Washable hence hygienic in use.
- ◆ Economical in price.
- ◆ Customized to size wherever required.

Certification

- ◆ EN ISO 11612. and NFPA 2112 Certified Fabric.

