



SAVIUR Airline 'SS' Box



General Description:

'Saviour' products are the most innovative solutions in themselves. On field observation leads to study of the problem which leads to the development of products and solutions satisfying customers' needs.

Products like 'Saviour' Air Line Box are the most innovative products which are well accepted for extended working where Breathing air is continuously required for ongoing operations.

MODEL NO: RPSAV-ASSB

Specifications

'Saviour' Air Line Kit consists of a strong yet light weight SS 304 cabinet of 3mm thickness which is lined for inner smoothing of surface and provided with locking arrangement to avoid pilferage. The Box houses a Hose Reel which is suitable to accommodate minimum 30 Meters of Hose and is provided on one side with a handle for ensuring the movement, at the same time the provision is made such that the QRC on the other end does not shift in position while winding or unwinding the Hose.

The Box also has a Shelf to house the Face mask and Regulator when required. It is provided with a Female QRC connection on the other side to attach to the Manifold. This can be either Trolley mounted or just Hung on the wall for ease of space and operation.

Box Dimensions : W 16" X L 17" X H 23" / **Weight:** 19.5 Kgs.

Applications

- ◆ Confined Space applications requiring long duration working.
- ◆ Long duration work requirements in hazardous atmosphere in Oil & Chemical industries.
- ◆ Industries requiring Sterilized equipment like Pharmaceuticals etc.

Advantage

- ◆ A unique Combination of protective Box hose reel and breathing arrangement.
- ◆ Economical extended hours breathing solution.
- ◆ All connections hydro tested and leakage free.
- ◆ Low maintenance cost.
- ◆ Easy to move to different locations if required.

Certification

- ◆ **Manufacturer's Test Certificate.**