

# Saviour Heat Shield Gloves




**Model No.: HNPSAV-SHS**



### General Description:

- Saviour Heat Shield is a heavy-duty special purpose glove offering high levels of molten splash resistance. Ideal for many different applications requiring thermal protection, it also provides superior durability and good protection from cuts, punctures and abrasions.
- Heat protection for a wide range of applications. The Saviour Heat Shield glove is certified as a Category III glove for protection against high temperatures and is rated with the EN 407 performance levels. This makes the glove suitable for a large number of applications requiring heat resistance, including welding, operating machinery and working in environments with a risk of heat or molten splash.
- With a soft inner jersey palm lining and a cotton denim cuff, Saviour Heat Shield glove is comfortable to wear.
- Excellent durability and mechanical protection. Made of tough-wearing leather, this heavy-duty glove is designed with palm reinforcement for added abrasion resistance.
- Seams are made in Kevlar<sup>®</sup> are reinforced by pieces of cowhide. This construction provides superior mechanical protection rated with EN388

### Primary Industries:

-  Automotive
-  Machinery & Equipment
-  Metal Fabrication

### Certifications:



EN 388-4344



EN407-423X4X

### Specifications:

Construction	: Cut & sewn
Liner material	: Split Leather, Kevlar Seams
Cuff Style	: Gauntlet
Colour	: Yellow
EN SIZE	: 10
Length in MM	: 415
Packaging	: 72 pairs/Carton

**Applications:** Loading and unloading with risk of heat or molten splashes | Heavy welding