

**SAVIOUR<sup>®</sup>**

Performing PPE



**SAVIOUR TOUGH HAT  
HELMET**

[www.suresafety.com](http://www.suresafety.com)

**Sure<sup>®</sup>  
Safety**  
Complete Safety Solutions

# Saviour Tough Hat Helmet







Protecting the head is essential in manufacturing settings to prevent injuries from falling objects or accidents. Saviour Tough Hat Industrial Safety Helmets fulfill this need, offering complete head protection with wearer comfort in mind. Ideal for inspection, design, fieldwork, and workshop tasks, these helmets are crafted for durability and safety in industrial environments, safeguarding workers from various hazards.



Ratchet



Pin Lock

TECHNICAL SPECIFICATION				
Model No.	HPSAV-THR-ABS	HPSAV-THR	HPSAV-TH-ABS	HPSAV-TH
Material	ABS	HDPE	ABS	HDPE
Size	520 to 600 mm	520 to 600 mm	520 to 600 mm	520 to 600 mm
Ratchet	√	√	X	X
Suspension	6-point polymer suspension	6-point polymer suspension	6-point polymer suspension	6-point polymer suspension
Chin Strap with chin cup	√	√	√	√
Sweat Band	Soft PU	Soft PU	Soft PU	Soft PU
Colour	<div> White</div> <div> Blue</div> <div> Yellow</div> <div> Red</div> <div> Green</div> <div> Orange</div>			
Logo	Logo printing and branding options available for bulk orders			
Reflective strips	Reflective strips options available for bulk orders			



## FEATURES

Comfortable Design	Ergonomic design and special brim structure for user comfort.
Adjustable Fit	Customized fit with adjustable chin strap and headband.
Soft Sweatband	Conforms to head contours, maximizing sweat absorption.
Wide Applications	Suitable for various industrial segments requiring complete head protection.
Safety Certified	Certified to IS 2925:1984 (Rev.2005) safety standards.
Impact Resistant	High-impact polyethylene shell for protection against heavy blows.
Accessory Compatibility	Compatible with various accessories for enhanced versatility.
Impact Protection	Utilizes high-impact shell and shock-absorbing foam for superior head protection.
Visor Compatibility	Easily attaches optional visors for added face protection.
Lightweight and Durable	Minimizes strain with lightweight build and ensures durability.

## APPLICATION

- Erection/Commissioning
- Fabrication
- Pipeline Installation
- Mechanical Workshops
- Construction Projects
- Maintenance Operations
- Manufacturing Facilities
- Warehouses
- Mining Sites
- Oil & Gas Facilities
- Utility Maintenance

## ADVANTAGES

- High impact resistance for enhanced safety.
- Ergonomic design for ease of wear and increased comfort.
- Soft sweatband for maximum comfort and sweat absorption.
- Adjustable chin strap for proper fitment and increased safety.
- 6-point suspension for uniform fitment and user comfort.

## MAINTENANCE

- Clean with mild soap and water regularly to remove dirt and debris.
- Inspect regularly for signs of wear, damage, or deterioration.
- Replace if any components are damaged or compromised.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

## CERTIFICATION

**IS 2925:1984**



**CM/L-7572484**

**EN 397:2012**

## RECOMMENDED ACCESSORIES



Saviour Face Shield  
Model No.: FPSAV-FSP



Saviour Series 2 Safety Eyewear  
Model No.: EYSAV-SERIES 2C



Saviour Helmet Mounted Ear Muffs  
Universal  
Model No.: EYSAV-EF

**EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)**

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.