

## ***Universal Metal Bracket Face shield***



### **General Description:**

Many a times protection is required not only for the Head but also entire face. This is required mostly in Mechanical workshops besides protection requirement against Chemical Splash both Indoors and in the Field. Similar protection is also sometimes required in areas where heat is prevalent or generated as a result of operational requirements.

'Saviour' Aluminum Bracket Face Shield with optically clear Visor adapts to the Helmet with ease for ensuring perfect protection in such cases.

**MODEL NO: FP-AL-B4**

## Specifications

'Saviour' Aluminum Bracket Face Shield with Blue Visor comprises of Light weight Aluminum bracket attached to a high tensile Spring with swivel posts locking the visor in place. The Visor is made up of acrylic Plastic with 100 % optical clarity mounted on Aluminum Bracket. Face Shield Visor is of high impact resistance and is 4mm thick. Visor comes in size of 8" x 13" which gives maximum safety especially in high heat areas. The Visor is replaceable and hence economical. The Brackets come in Universal sizing arrangement which can fit on any helmet.

## Applications

- ◆ Mechanical Engineering Workshops incorporating Grinding / Chipping Welding operations.
- ◆ Foundries, Furnace and Kiln Industries.
- ◆ High heat field operations like joining pipes on field etc.

## Advantage

- ◆ Biggest advantage is use along with Helmet so it gives both Head and Face.
- ◆ Protection against Chemical splash, Flying Objects, grinding Chips etc.
- ◆ Replaceable Visor hence economical to use.
- ◆ 4 mm thickness of visor gives high impact resistance and excellent in high heat areas.
- ◆ Optical clear visor gives perfect vision.
- ◆ Easily attached to any Helmet

## Certification

- ◆ **CLI Certification**

