



## SAVIOR Freedom Helmet with 'Ratchet Head Band' (HDPE/ABS)



### General Description:

Inside Temperature Decreases 6° C to 8° C

Head protection is a must for every type of Manufacturing Facility. It is the basic need of any Industry or Field activity however big or small.

'Saviour' Freedom Industrial safety Helmets with ventilation Holes are just the right helmets for such protection requirements as they not only provide complete protection but also are comfortable to wear as they ensure dissipation of heat during extended wear.

**MODEL NO:** HPSAV-FR-SS1/  
HPSAV-FR-ABS

## Specifications

Freedom Helmets with Ventilation Holes are made out of Virgin Grade Engineering Plastic HDPE material. The weight of the Helmet does not exceed 435 gms. The inner dimensions of the shell are between 520 to 600 mm.

They incorporate Aero-Dynamic design [Ergonomic] for comfort of user and have an extended nape for increased neck protection. 15 nos. Ventilation Holes are provided on Front, Back, sides and top of the Shell for easy flow of air to the Head portion for the comfort of the user. Frontal openings come with covers to protect against rain, water & excessive air when required. They are provided with 8 point Textile suspension made out of good Nylon Material with adjustable Nape Strap for user adjustment. Inner suspension is of 25 mm width for proper strength and functioning.

It has Chin strap of 19 mm width for proper fitment onto the shell and Head and is provided with Chin Cup made up of virgin grade LDPE for adjustment and proper snug fitting on the Chin for more safety.

Sweat Band made out of soft PU material is compatible to Skin and comes with high absorbent properties for maximum sweat absorption. Sweat Band is designed for snug fit to the forehead for maximum comfort and adjusts to contours of

## Applications

- ◆ All Industrial segments demanding complete Head protection both Indoor and outdoor.
- ◆ High Heat areas like Erection / Commissioning / Fabrication–Laying of Pipelines.
- ◆ Foundries. Furnaces & Kilns etc.
- ◆ Mechanical Engineering workshops.
- ◆ Construction Industry.

## Advantage

- ◆ Complete Head Protection with Provision for Heat dissipation during extended working in the Field due to 15 ventilation Holes.
- ◆ Higher Impact resistance ensures higher Safety.
- ◆ Aero-Dynamic designs ensures ease of wear and more Ergonomic comfort.
- ◆ Soft Sweatband ensures adjustment to head contours for ease of wear and absorption of sweat ensuring comfort to the wearer.
- ◆ Adjustable Chin strap ensures proper fitment ensuring higher Safety.

## Certification

- ◆ **IS 2925:1984 certified.**
- ◆ **Complies to EN:397.**