



SAVIOUR INFLATABLE BOAT

Model No.: RSC-IRB

Saviour Inflatable Boat



TECHNICAL SPECIFICATION

Model	Overall	Overall	Floor	No.of Chamber	Net	Max (H.P)	Max	Max Person	Package Size
	Length	Width			Weight		Load		
	(cm)	(cm)			(kg)		(kg)		(cm)
FWS- 450	450	200	Air Mat	5+2+1	95	50	1000	8	150x85x50

KEY FEATURES

- Suitable for use with 2 or 4 stroke short shaft outboard motors up to 30hp (max weight 65kg)
- Easy handling requires less crew effort
- Can be deflated and stored in a carrying valise. The boat, motor and the crew PPE equipment will fit in the back of a small van, therefore no need for a trailer, can be carried by 2-3 people
- Fitted with central bow towing point and bridal attachment points. Additional towing points are fitted onto the transom
- The large usable deck area allows up to 10 people or 800Kg of equipment to be carried
- Twin keel design produces minimal wake, reducing potential damage to river banks and offers excellent manoeuvrability
- A high volume drain sleeve is fitted to the transom in addition to drain plug
- Self-filling/draining water ballast chambers on the outboard side of each keel help to increase low speed lateral stability in choppy waters and act as counterbalance when recovering a casualty over the side tube.
- Will operate in 10 cm of water without the motor fitted and can also be manoeuvred in shallow water by persons walking alongside
- With motor fitted it is suitable for use in shallow water >40cm (depending on the outboard engine)
- Internal control line rings are provided for use with the bow and stern towing points for tandem boat operations
- The flat front provides easier bow boarding and a greater usable interior space
- Wide beam gives excellent stability and increases floor area
- Rapid inflation and deployment (less than 5 minutes)

ACCESSORIES

- Hand pump-1pc
- Foldable boat bag-1pc
- Aluminum paddle-1 pair
- Repair kit- 1pc

APPLICATION

- River rescue
- Coastal and urban flood recovery
- Casualty recovery
- Shallow water rescue

EXPLORE MORE AT: WWW.SURESAFETY.COM

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.