



9460

All new and more powerful 9460 Remote Area Lighting System (RALS) provides convenient and ecologically responsible alternatives to wasteful generator powered lights. Engineered with the Intelligent Control System which calculates and displays current battery life. Additionally, it allows the user to regulate the intensity of the light, choose the desired run time or select from three pre-set power levels. Built with versatility in mind, the 9460 RALS features two telescopic masts (each extends to nearly 6 feet) and two 360° articulating light heads. The system's next-generation LEDs combine to radiate up to 12,000 lumens (6,000 per light head). For extended applications, the 9460 can run continuously on wall power. The ability to leave on charge allows you to always be prepared. A 12volt power port including a dual USB adapter provides power for multiple peripheral devices. Built self-contained in a tough-as-nails Pelican case, the 9460 is compact and provides easy ground transport with a retractable pull handle and stainless steel ball-bearing polyurethane wheels.

CAUTION: The Pelican Products RALS models 9460 and 9470 contain sealed lead acid batteries that can generate hydrogen gas when charging. It is imperative that these products are charged, as instructed, with the case lid open to allow any gases to escape as charging with the lid closed poses a significant hazard. Failure to abide by this instruction could result in injury and/or damage to property. Please refer to the warnings provided in the instructions for the unit and on a decal affixed to the inside of the case adjacent to the cavity where the charger unit is packed.

NEW UPGRADED SPECS

- Dual telescoping LED light heads
- Housed in a Pelican™ Protector Case™ housing
- Silent operation
- Cool operating temperatures
- No exhaust
- Full time battery level indication with low level flashing indicator
- Upright and lie flat pole brackets
- Dual USB power adapter
- RoHS and CE Compliant



DIMENSIONS

Head (LxWxD)	8.25 x 5.75" x 2.25 (21 x 14.6 x 5.7 cm)
Closed (LxWxD)	23.25 x 14.00" x 9.25 (59.1 x 35.6 x 23.5 cm)
Light Head Height (max)	79.50" (201.9 cm)
Cord Length	13.78" (35 cm)

MATERIALS

Body	Polypropylene
Head	Aluminum
Mast	Aluminum
Lens	Polycarbonate (PC)

COLORS

 Black	 Yellow
---	--

LIGHT SPECS

Lumens (High)	12000
----------------------	-------

Lamp Heads	2
Lamp Type	LED
Number of LEDs	20
Beam Spread	120°
IP Rating	54

POWER

Run Time (High)	3.00 hrs
Run Time (Low)	24.00 hrs
Battery Type	Sealed Lead Acid (SLA)
Rechargeable	yes
Battery Lifespan	500 cycles
Charge Time	8 hrs
Battery Level Indicator	iControl
Sockets (Primary)	2
Volts	12.0v

WEIGHT

Weight	61.00 lbs (27.7 kg)
---------------	---------------------

SWITCH

Switch Type	iControl Keypad
--------------------	-----------------

Pelican

23215 Early Ave • Torrance, CA 90505 USA • Phone: (310) 326-4700 • (800) 473-5422 • Fax: (310) 326-3311
sales@pelican.com • www.pelican.com

Document created on 07-22-25