



Performing PPE



**5 LAYER  
PROTECTION**

Heat Reflective  
Thermal Resistance  
Flame Resistance  
Water Proof  
Comfort Protection

## SAVIOUR ALUMINIZED ARAMID SUIT

Model No.: BPSAV-AALS5

[www.suresafety.com](http://www.suresafety.com)

**Sure**  
**Safety**  
Complete Safety Solutions

## Saviour Aluminised Aramid Suit

The Saviour Aluminized Aramid 5-Layer Suit is a premium protective garment meticulously engineered to provide superior protection against heat, fire, moisture, and other workplace hazards. Constructed with five specialized layers, each serving a specific purpose, this suit offers exceptional safety, comfort, and durability for workers in demanding industrial environments.

### KEY FEATURES

#### One-Piece / Three-piece Design:

- Comprehensive coverage
- Ease of wear for the user

#### Aluminized Film (Heat Reflective):

- Reflects radiant heat
- Minimizing heat absorption
- Maximum protection in high-temperature environments.

#### Fiber Glass (Thermal Layer):

- Provides thermal insulation from intense heat and flames.

#### Aramid Layer (Flame Resistant):

- Additional thermal resistance
- Barrier against heat and flames

#### Moisture Barrier (Waterproof):

- Prevents moisture, liquids, and chemicals from penetrating the suit, maintaining dryness and comfort for the wearer.

#### FR Inner Layer (Comfort Protection):

- Flame-resistant inner layer for comfort and protection against direct contact with the skin

#### Aramid thread Stitching:

- Suit stitched with Aramid thread for enhanced fire resistance and durability.

#### Integrated Breathing Apparatus Compatibility:

- Rear portion designed to accommodate a breathing apparatus, enhancing user safety and comfort.

### COVERALL BPSAV-AALS5-C



### 3 PIECE SUIT BPSAV-AALS5-HCP



EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.



## ACCESSORIES INCLUDE:



Hood with visor  
& Helmet cover



Insulated hand  
gloves



Heat Resistant  
Shoes




Bag

## TECHNICAL SPECIFICATIONS

Material Layers	a. Aluminized Film b. Fibre Glass c. Aramid Layer d. Moisture Barrier e. FR Inner Layer
Suit Layers	5
Stitching	Aramid thread
Breathing apparatus compatibility	Rear portion designed to accommodate breathing apparatus
Included accessories	Insulated Hand Gloves, Hood integrated with Helmet and Visor, Heat-Resistant Shoes
Packaging	Duffle Bag

## MATERIAL COMPOSITION



## APPLICATIONS

1. Foundries and metal casting operations
2. Steel mills and metalworking industries
3. Welding and cutting operations
4. Firefighting and emergency response
5. Chemical processing and petrochemical industries
6. Electrical utilities and power generation facilities

## CARE INSTRUCTIONS

1. Follow manufacturer's instructions for cleaning and maintenance.
2. Inspect regularly for signs of wear or damage and replace if necessary.
3. Store in a clean, dry area away from direct sunlight and moisture when not in use.
4. Ensure proper storage of included accessories to maintain their integrity and effectiveness.

## CERTIFICATION



EN ISO 11612

Tested as per ISO 11612

## RECOMMENDED ACCESSORIES



Breathing Apparatus Set  
IS 10245-2, IS 14166,  
EN 137, EN 136  
certified

EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.