

SAVIUR[®]

Performing PPE



SAVIUR ELSA (EMERGENCY LIFE SUPPORT APPARATUS)

Model No.: RPSAV-ELSA

www.suresafety.com

Sure[®]
Safety
Complete Safety Solutions

Saviour ELSA (Emergency Life Support Apparatus)

The Saviour ELSA is a specialized escape breathing device engineered for swift evacuation from hazardous industrial and marine environments. Known for its reliability and robust design, it delivers continuous air supply, ensuring optimal protection during emergency scenarios. Available in durations of 10 or 15 minutes, the ELSA comes in high visibility PVC or black anti-static polyurethane materials. Comprising a cylinder with a combined valve and reducer, a supply hose leading to a constant flow hood, and a convenient stowage bag, the ELSA apparatus is activated by opening the bag, initiating a prompt escape process.



TECHNICAL SPECIFICATIONS

BODY		HOOD	
Material	PVC -coated Nylon	Material	Flame-retardant PVC-coated materials comfortable.
Visibility	Fluorescent orange	Comfortable Fit	Enhanced with vibrant colouring.
Properties	Flame-retardant and chemical splash resistant.	Visor	Clear Visor
Wear Style	Designed for chest wearing in a bandolier fashion.	Enhanced Performance	Includes exhale valve for improved overall performance

CYLINDER OPTIONS

Material	Capacity	Duration
Steel Cylinder	2L/200bar	10 Minutes
Steel Cylinder	3L/200bar	15 Minutes
Aluminum Cylinder	2L/200bar	10 Minutes

ADVANTAGES

- Lightweight system
- User Friendly
- Reliability
- Customizable Duration
- Comfortable Design

CERTIFICATION

Compliance to IS 10245 (Part -4): 1982, Reaffirmed 2002)

EXPLORE MORE AT: WWW.SURESAFETY.COM

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.