



## SAVIOUR PAINT AIR FED PAINTING HOODS

Model No.: RPSAV-AFPH

## Saviour Piant Air Fed Painting Hoods

The 'Saviour' Paint Air Fed Painting Hoods are designed for Protection of personnel in paint spraying and light finishing applications. These Hoods provide not only Respiratory protection but are equipped with features to enhance user safety and comfort which include adjustable regulator and a dual-function alarm that includes both visual and audible alerts, the hood provides effective monitoring of crucial parameters. These hoods offer a versatile solution for various industrial tasks.



### TECHNICAL SPECIFICATIONS

Air Flow Rate	Adjustable between the range of 170 - 250 litres per minute.	Hose Length & System Pressure	<ul style="list-style-type: none"><li>Hose dia: 3/8"(9.5mm)</li><li>Requires a minimum air pressure of 3.5 bar @ 250 litres per minute.</li><li>Pressure to be available at a distance of 10 meters from the belt-mounted pressure regulator.</li></ul>
Belt	Adjustable to fit waist sizes from 22" to 50".	Low Flow Warning	The low flow warning system, with a whistle and gauge, utilizes technology to alert users if air pressure drops below a safe level, ensuring continuous safety during operations.
Belt Buckle	Made out of strong 'Acetal' material for durability.	Regulator	The adjustable regulator with varied air flow rates between specified limits showcases advanced technology in regulating and optimizing air supply for user comfort
Brow guard	Made out of Virgin ABS.		
Disposable Visor	Each unit includes a pack of spare visors: <ul style="list-style-type: none"><li>Interwoven polyester for high optical quality and strength.</li><li>Tinted version available</li></ul>		
Field of Vision	Provides over 85% .		
Flammability	<ul style="list-style-type: none"><li>Flame Retardant</li><li>Does not Drip or Melt when subjected to a flame at 800 degrees C</li></ul>		

### CERTIFICATION

Manufacturer Certificate

### RECOMMENDED ACCESSORIES



**Saviour ventair suit**



**Saviour Nitrile Advance Gloves**

### APPLICATIONS

1. Paint Spraying and Finishing
2. Industrial Painting Operations
3. Automotive Painting
4. Construction and Maintenance Painting
5. Shipbuilding and Maritime Applications
6. Aerospace Industry
7. Custom Coating Applications

EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.