



## SAVIOUR VENTO HELMET- VENTILATED

## Saviour Vento Helmet- Ventilated

Ensuring head protection is paramount across all manufacturing facilities, regardless of their size or scale of operation. The 'Saviour' Freedom Industrial Safety Helmets with ventilation holes stand out as the optimal choice for meeting these crucial safety needs. These helmets not only provide comprehensive protection but also prioritize wearer comfort. Featuring a specialized design with strategically placed ventilation holes, they effectively dissipate heat during extended wear, ensuring a comfortable experience without compromising safety.









Ratchet



Pin Lock

### TECHNICAL SPECIFICATION

Model No.	HPSAV-VEV-ABS-R	HPSAV-VEV-R	HPSAV-VEV-ABS	HPSAV-VEV
Material	ABS	HDPE	ABS	HDPE
Size	520 to 600 mm	520 to 600 mm	520 to 600 mm	520 to 600 mm
Ratchet	√	√	√	√
Ventilation Hole	10	10	10	10
Suspension	4-point polymer suspension	4-point polymer suspension	4-point polymer suspension	4-point polymer suspension
Chin Strap with chin cup	√	√	√	√
Sweat Band	Soft PU	Soft PU	Soft PU	Soft PU
Colour	<div><div> White</div><div> Blue</div><div> Yellow</div><div> Red</div><div> Green</div><div> Orange</div></div>			
Logo	Logo printing and branding options available for bulk orders			
Reflective strips	Reflective strips options available for bulk orders			

EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.

## FEATURES

1. Advanced Ventilation System: Improves airflow, prevents overheating, and boosts wearer comfort.
2. Impact Protection: Utilizes high-impact shell and shock-absorbing foam for superior head protection.
3. Adjustable Fit: Secures a customized fit with adjustable chin strap and headband.
4. Visor Compatibility: Easily attaches optional visors for added face protection.
5. Lightweight and Durable: Minimizes strain with lightweight build and ensures long-lasting durability.
6. Complete Head Protection: Provides heat dissipation through 10 ventilation holes.
7. Higher Impact Resistance: Meets safety standards, ensuring increased safety.
8. Aero-Dynamic Design: Offers ergonomic comfort with its aerodynamic design.
9. Soft Sweatband: Conforms to head contours, maximizing sweat absorption.
10. Adjustable Chin Strap: Guarantees proper fitment and safety.

## APPLICATION

- Construction sites
- Industrial facilities
- Manufacturing plants
- Warehouses
- Maintenance and repair operations
- Utility and infrastructure work
- Outdoor work environments
- All industrial segments requiring complete head protection indoors and outdoors.
- High-heat areas such as erection, commissioning, fabrication, and laying of pipelines.
- Foundries, furnaces, and kilns.
- Mechanical engineering workshops.
- Construction industry.

## CERTIFICATION

**IS 2925:1984**



**CM/L-7572484**

## MAINTENANCE AND CARE

- Clean with mild soap and water as needed.
- Inspect regularly for signs of wear or damage.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

## RECOMMENDED ACCESSORIES



Saviour Face Shield  
Model No.: FPSAV-FSP



Saviour Series 2  
Safety Eyewear  
Model No.: EYSAV-SERIES 2C



Saviour Helmet  
Mounted Ear Muffs  
Universal  
Model No.: EYSAV-EF

**EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)**

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.