

**SAVIUR**<sup>®</sup>

Performing PPE



## SAVIOUR FALL ARRESTOR BLOCK

Model No.: FP-FAB

R2/070126

[www.suresafety.com](http://www.suresafety.com)

**Sure**<sup>®</sup>  
**Safety**  
Complete Safety Solutions

## Saviour Fall Arrestor Block

Accidents due to fall from Heights are usually fatal if no Fall protection system or a fall device is used by the workmen. The choice of the fall arrest system must be based on the site conditions and requirement of the work. Whatever the fall arrest system chosen (fall arrester on anchor line, retractable fall arrester, energy absorbing lanyard) it guarantees a fall arrest. 'Saviour' 'Fall Stop' is one of the many solutions for where the is designed to arrest a fall and to limit the impact generated by the slowing down, without causing injuries to the user's body or the workmen.



### TECHNICAL SPECIFICATION

Operating Mechanism	Inertia-based locking system similar to a vehicle safety belt; allows smooth extension/retraction and locks instantly during sudden fall or impact	Housing	High-strength plastic molded enclosure
Lifeline	Retractable wire rope	Operating Temperature Range	-30°C to +50°C
Wire Rope Diameter	4.8 mm	Snap Hook	Alloy steel swivel snap hook
Wire Rope Material	Stainless Steel (SS) / Galvanized Iron (GI) with steel core	Snap Hook Weight	400 grams
Minimum Breaking Load (Wire Rope)	1350 kg	Breaking Load (Snap Hook)	23 kN
Ultimate Tensile Strength	1960 N/mm <sup>2</sup>	Gate Opening	18 mm (for free movement)
Total Weight	≤ 7 kg	Peak Arrest Force	> 6 kN
		Average Locking Distance	0.4 meters
		Minimum Clearance Required Below User	1.5 meters
		Size	Available in 6, 10, 12, 15, 20 Feet

EXPLORE MORE AT: [WWW.SURESAFETY.COM](http://WWW.SURESAFETY.COM)

DISCLAIMER: Manufacturer will not be responsible for any mishandling and wrong usage of the product shown picture is just for representative purposes only, actual product may differ.

### KEY FEATURES

- Light in weight / Ease of use / Compact yet sturdy.
- Offers Swivel movement for Flexible usage.
- Very High Load Carrying capacity.
- Corrosion resistant / Excellent for Inclement weather conditions.
- Resistant to both Hot and Cold temperature.

### APPLICATIONS

- Confined space entry / Excavations
- Vessel Entry
- Rescue operations
- Silos and towers
- Landfill protection / Construction industry
- Oil & Gas segments
- Utilities department in industry

### CERIFICATIONS

- Conforms EN 360